

**MICHELMAN®**

# **Preliminary Studies on the Effect of Polymeric Film Formers and Cross Linking Chemistries on the Water-Glycol Resistance of PA-Glass Fibre Composites.**

**Steve Bassetti**

Global Marketing Director

**Nagesh Potluri, Ph.D**

Group Technology Director

This document contains trade secrets or otherwise confidential information owned by Michelman, Inc. Access to and use of this information is strictly limited and controlled by Michelman, Inc. This document may not be copied, distributed or otherwise disclosed except where expressly authorized by Michelman, Inc.



# Who We Are

## Innovating a Sustainable Future

- Environmentally conscious
- Customer focused
- Family owned
- Global
- Professionally managed
- 70 years of experience



Global Headquarters – Cincinnati, OH

# Our Vision: The Interface Experts

- Industrial Manufacturing Group Mission
  - To become the **Interface Adhesion Experts** delivering new solutions to the Composites Value Chain through new and differentiated technology, proven and validated with industry-standard equipment, testing, and data.
  - To optimize the interface adhesion between Fibers and Polymers across **all types** of composites, whether Thermoplastic or Thermoset.



# Complete Composites Portfolio

- **Michelman** develops film formers and surface treatments to serve **ALL** fiber types:

- Glass
- Carbon
- Basalt
- Natural
- Synthetic



- **Targeted Applications**

- Polyolefin Thermoplastics
- Polyamide Thermoplastics
- Thermosets
- UD Tapes
- Technical Textiles
- Pre-Pregs

# Typical Fiberglass Sizing Formulation

- 80-90% Film Former=**Major Component**
  - Facilitates fiber manufacturing
  - Protects and bonds filaments together
  - Compatibility/adhesion promoter
- 5-10% Silane Coupling Agent
  - Adhesion promoter
  - Wet strength
- 5-15% Size Modifiers
  - Lubricants, anti-stats, antioxidants
  - Wetting agents, processing aids



# Focus on PA-66 Research



- **High Temperature Thermoplastics** continue to remain “**hot**” and “**in-demand**” technology in several applications
  - Metal replacement in automotive industry
  - Longer lifetime of oil and gas assets
  - Air intake manifolds, rocker covers, radiator end tanks, electrical connectors and others.
- **Polyamides** are generally used for their excellent balance of **oil resistance, thermal stability, mechanical strength**, and other desirable properties.




# Problem statement: Interface Failure

- **What is happening?**

- Failure at the interface of fiber and PA-66
- Glycol is damaging the bonding
- Better chemistry is needed



# Interface in a glass fiber composite




- Improve interaction between matrix and fiber through **SIZING**
- Introduction of **reactive chemistry**
- Glycol resistant film former(s)



# Film Formers for PA-66

- Polyurethane polymers in form of dispersions (PUD) are used for many polyamide applications
- For PA-66 glycol resistance is most effective by using a combination of film formers
- Michelman designs PUD's by adjusting **building blocks**. (PUD1, PUD2)
- Copolymers of reactive polymers are used as co-film formers to boost glycol resistance in PA-66.

## POLYURETHANE DISPERSION




# Materials and Methods

- **E-Glass** – Leibniz-Institut für Polymerforschung Dresden
- **Fiberglass Sizings\*** - Michelman
- **Resin – PA 66 Ultramid A27 E**
- **Extrusion and Molding** - Leibniz-Institut für Polymerforschung Dresden
- **Tensile Testing ISO 527A (DAM and After glycol)** - Michelman
- **Glycol Resistance Test** - Michelman
- **SEM Images** – Michelman

# Michelman Sizing Chemistries

	Film Former	Co-Film Former
M1	PUD-R	RP-1
M3	PUD	RP-1
M4	PUD-R1	RP-1
M5	PUD-R1	RP-1
M6	PUD	RP-2
M7	PUD-R	RP2




RP = Reactive polymer

PUD-R= Reactive PUDs


PUD= Conventional PUDs

\* All sizing formulations had the same % of Amino propyl silanes



# Tensile Modulus of as molded (blue) and after Glycol soaking (orange)



# Tensile Strength of as molded (blue) and after Glycol soaking (orange)




# Improved interface



**\*Adhesion between matrix and fiber has improved**

# Composites Collaboration Center



# Conclusions

- Our results indicate retention of 35-37% in tensile strength and 49-53% in Tensile modulus.
- PUDs in combination with reactive polymers have resulted in performance equivalent to current incumbent solutions (M1).
- Although we currently don't have a winning candidate, this study has provided us an understanding of current state of art of film formers that resist glycolysis.
- In working with our partners, we are building a better understanding of structure/property relationships between fibers and matrices.
- The knowledge gained through this work will help us in designing next generation film formers and co-film formers for improving glycol resistance.



# Future Work

- Interfacial Shear Strength is a unique and valuable test method to determine fiber/matrix interaction.
- Work is underway to establish a correlation between single fiber pull out and bulk mechanical properties
- Additional work will continue to improve our understanding of the fiber/matrix interactions, specifically as they relate to glycol resistance.
- We will continue to explore the relationships between Silanes, film formers, and reactive polymers with the goal to optimize the entire sizing system.
- This work is an ongoing effort, with several variables that will be systematically studied.

MICHELMAN®

Thank you!

Any questions?

